

Dimensions in mm

Properties

Cover kit with fixing



- for Range 801 / 805 Classic stationary support and hinged supports rails
- for Range 801 / 805 Classic shower spray guards

For installation on lightweight walls you will need a rear lining, e.g. laminated timber boards, with waterproof bonding >20 mm thick. 30 mm thickness required, for example, Support stand or wall installation)

Consisting of:

- 2 stainless steel screws
- 2 stainless steel Rampa sleeves
- 2 caps made of high-quality polyamide in HEWI colour 99 (pure white)
- 2 bases made of high-quality black polyamide

Colours / Surfaces

-  99 (pure white)
-  74 (apple green)