



Dimensions in mm

Properties

Fixing type

for one-sided handle fixing on hollow profiles. For handles with inclined supports.

Drillhole in the door with 14 mm diameter. Installation tool: spanner SW6 (A/F 6).

Assembly instructions

A distance of at least 15 mm is required between the first and second wall is required for installation of the pushin nut.